



IMPORTANT

Disconnect power before installing fixtures. Read instructions before starting work. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Streamline 6002/6005 Series

FIXTURE INSTALLATION INSTRUCTIONS

Please note: Luminaires are factory assembled for the specified orientation (6002 indirect up or 6005 direct down). Mounting screws are always located on the bottom side. Above images are for reference only, refer to specification page for actual orientation and options.

- 1 Remove luminaire from shipping carton
- 2 Undo (10) machine screws and remove ballast box cover and lens frame. Not required for LED models.
- 3 Position mounting plate over 4" junction box checking for level horizontal installation.
- 4 Secure mounting plate to mounting surface independent from junction box with (4) mounting screws (not supplied, must be suitable for load application).
- 5 Working inside ballast box select appropriate voltage leads and push leads through wire access hole in back of ballast box. Cap off unused leads and leave in ballast box. Not required for LED models.
- 6 Connect fixture leads to supply leads with approved wire connections and push supply leads and splices securely into junction box.
- 7 Hook fixture at back of ballast box over mounting plate making sure that no wires are pinched.
- 8 Tighten (2) mounting set screws until fixture is secure against mounting surface.
- 9 Caulking must be applied between fixture and mounting surface to create watertight seal. Wet location listed only.
- 10 Loosen adjustment nuts (2) and alignment set screws. Adjust cast housing to desired angle (+/- 15°) and re-tighten adjustment nuts then set screws. Adjustment hardware located inside ballast box.
- 11 Install designated lamp into lampholder. Not required for LED models.
- 12 Re-install ballast box cover and lens frame, making sure there are no obstructions between gasket and frame that will interfere with seal. Tighten machine screws (4 on ballast cover and 6 on lens frame) in a circular pattern to insure a uniform pressure against gaskets. Tighten to 8ft/lbs torque to create watertight seal.
- 13 Energize and test as required.

REV 03/1/17