



IMPORTANT

Disconnect power before installing fixtures. Read instructions before starting work. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Saturna 4009 Series

ANCHOR BOLT INSTALLATION INSTRUCTIONS

- 1 Remove anchor bolt assembly from shipping carton.
- 2 Anchor bolts are to be embedded in concrete as follows. Position anchor bolts @ 90° spacing on 8" bolt circle diameter (template provided). Anchor bolts must protrude a minimum of 1.5" above finished concrete (if using shims for leveling) or 2" above finished concrete.
- 3 The appropriate rigid conduit, suitable for the application and in compliance with the local electrical code requirements, shall be routed prior to pouring concrete.

FIXTURE INSTALLATION INSTRUCTIONS

- 1 Remove luminaire from shipping carton and disassemble as follows. Loosen (3) locking set screws and remove guard assembly and glass lens.
- 2 Working from bottom of fixture, connect fixture leads to supply conductors with approved wire connectors. Align mounting plate/post assembly over embedded anchor bolts. Use shims provided as required for leveling.
- 3 Alternately, extra hex nuts that are provided may be used for leveling. Screw (4) hex nuts to bottom of embedded anchor bolts. Install mounting plate/post assembly. Level as required. Grout between finished concrete surface and mounting plate.
- 4 Install mounting brackets on (2) sides (for optional base cover only) as shown in diagram. Install washers and hex nuts provided with anchor bolt set and tighten securely.
- 5 Slide base cover (optional) over post and down to base. Secure with (2) flat head machine screws provided.
- 6 Install lamp (by others) re-install glass lens and guard assembly. Energize and test as required

REV. 1208/09