



**IMPORTANT**

Disconnect power before installing fixtures. Read instructions before starting work. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

# Streamline 6030D Series

## INSTALLATION INSTRUCTIONS

- 1 Remove fixture from shipping carton.
- 2 Loosen (2) set screws and remove shroud assembly from fixture.
- 3 Remove (2) mounting screws and electrical tray from mounting plate.
- 4 Remove (2) j-box screws from j-box.
- 5 Pull supply leads through grommet in mounting plate and position mounting plate over j-box. Install (2) j-box screws through mounting plate and into j-box. Check for level then tighten j-box screws. Alternately (4) outboard mounting holes can be used instead j-box screws.
- 6 Attach electrical tray leads (black, white & green) to supply leads with wire nuts (by others) and push connections securely into j-box.
- 7 Install appropriate lamp (see lamp label information).
- 8 Install shroud assembly and tighten set screws until secure.
- 9 Energize and test as required.

REV. 12/08/09