



IMPORTANT

Disconnect power before installing fixtures. Read instructions before starting work. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN.

Encore ENC0 Wall Mount

INSTALLATION INSTRUCTIONS

1. Remove luminaire from carton.
2. Loosen (2) set screws located on the bottom side of the driver / wall canopy. Remove mounting plate.
3. Mounting plate is designed to attach to the ears of the outlet box. A 2" x 4" rectangle utility / switch / device box is required (by others).
4. Connect the black, white and green wire leads from the LED drivers to the wire leads located in the junction box with approved wire nuts (not supplied) and push these connections carefully into the junction box.
5. The housing assembly hooks over the mounting plate and is secured with (2) set screws loosened in step 2. Do not over-tighten but ensure assembly is secured against wall surface.
6. Energize and test as required.
7. This fixture is supplied with an LED as specified for the project and is self contained.
8. For exterior / wet locations, silicone sealant should be applied to the top and down both sides of the canopy to exclude water entrance. Sealant between wall surface and housing canopy.